

CONTROLADOR / CONTROLLER

71-4932-00-00



Description


Kit d'éclairage en option, Blanc brillant

CARACTÉRISTIQUES TECHNIQUES

Type:	Accessoire
Tension / Fréquence:	220-240V/50Hz
Garantie (Années):	2
Unités par caisse:	1
Poids net (kg):	0.095
EAN:	8435381425227



MATIÈRES / FINITIONS



Download photometric file .ldt /.ies

Ceiling Fan Wall-Mounted Control Installation Instruction



■ IMPORTANT POINTS TO REMEMBER:

1. Read carefully and retain the instruction.
2. Please note that all fixed wiring appliances should be installed by a qualified electrician.
3. **To avoid possible electrical shock, be sure electricity is turned off at the main fuse box or circuit panel before wiring.**
4. Do not mount wall control near heat producing equipment.
5. Use of this control with some ceiling fans could result in fire, shock and serious personal injury. Use this ceiling fan wall-mounted control only with ceiling fan capacitor speed controlled only.
6. Make certain no bare wires are exposed outside the connectors.
7. This unit is to be used for the control of ceiling fans at AC220/230V 50Hz power supply only.

■ INSTALLATION INTRUCTIONS

1. Disconnect the power and remove the existing wall plate and switch.
2. If your ceiling fan is equipped with a pull chain switch, make sure to set the speed control at the highest speed before installing the wall control.
3. Set the knob on the wall-mounted control in the off position.
4. Make wire connections and secure with 2pcs wire connectors.
 - *Connect the White wire from the wall-mounted control with the wire from the A. C. power supply.
 - *Connect the Black wire from the wall-mounted control with the Black wire from the ceiling fan.
5. Secure the wall-mounted control to the outlet box with two screws provided. Then, the face plate clicks on the wall control. (Fig. 1)

■ WIRING DIAGRAM



* FUNCTIONS:

- 0: POWER OFF
- 3: LOW SPEED
- 2: MEDIUM SPEED
- 1: HIGH SPEED